


Bring the simplicity of Playaway all-in-one audiobooks to life for your staff and patrons with this how-to guide.



*To Turn Off: Hold down  for 3 seconds.

To Lock + Unlock Keypad: While in PLAY, quickly click power once;  or  symbol will appear on LCD screen.



start listening

 Plug earphones, speakers, or car adapter into the universal headphone jack on bottom of unit.

 Press the POWER button.*

 Press the PLAY button.

Enjoy your HD audiobook experience!

*Hint: If the power does not turn on, you may need to insert or replace the AAA battery.